

# STAGE PLOT

[Front]

**Vocal/Keys/Sax (C-Dub)**  
Sennheiser EW500 Wireless  
[Provided]  
w/ boom stand  
[House]

Tenor Sax  
AMT Wireless Mic  
[Provided] Direct out

Novation Keyboard  
[D.I. Needed]

In Ear Monitor  
Sennheiser EW IEM G4 (RIGHT)  
[Provided]

**Vocal/Conga (Porsche)**  
Sennheiser EW500 Wireless  
w/ boom stand

In Ear Monitor  
Sennheiser EW IEM G4 (LEFT)  
[Provided]

Kquinto 10" (wood)

Conga 11" wood  
Drumseat

**Drum Set**  
SM 58 W/ Boom Stand  
4 Piece Drum Set  
12", 14" Toms/14" Snare/20" Bass Drum  
20" Ride, (left) 16" Crash, (right) 13" Hats

**Track**  
Click  
[D.I. Needed]

Mix  
[D.I. Needed]

Bass  
[D.I. Needed]

**Monitor**

**Bass (Porsche)**  
Fender  
Rumble 100 W  
[Direct out]

**Monitor**

Guitar

## St Oshun Sound Board Input List

**Act:** St. Oshun

**Contact:** C-Dub

**Phone:** 262-389-8120

| Channel | Input                         | Mic                            | Stand              |
|---------|-------------------------------|--------------------------------|--------------------|
| 1       | Center Stage Right Vocal      | Sennheiser Wireless (Provided) | Boom               |
| 2       | Center Stage Right Conga #1   | SM57 or better                 | Clip on (provided) |
| 3       | Center Stage Right Conga #2   | SM57 or better                 | Clip on (provided) |
| 4       | Center Stage Left Keyboard #1 | Direct Box (needed)            |                    |
| 5       | Center Stage Left Bass Track  | Direct Box (needed)            |                    |
| 6       | Center Stage Left Mix Track   | Direct Box (needed)            |                    |
| 7       | Center Stage Left Click Track | Direct Box (needed)            |                    |
| 8       | Center Stage Left Vocal       | Sennheiser Wireless (Provided) | Boom               |
| 9       | Center Stage Left Saxophone   | Wireless DI (Provided)         |                    |
| 10      | Down Stage Right Guitar       | SM58                           |                    |
| 10      | Down Stage Right Bass Guitar  | Direct Out of Amp              |                    |
| 11      | Down Stage Center Kick Drum   |                                | Short boom         |
| 12      | Down Stage Center Hi Hat      |                                | Boom               |
| 13      | Down Stage Center Snare Drum  |                                | Boom or clip on    |
| 14      | Down Stage Center Rack Tom    |                                | Clip on            |
| 15      | Down Stage Center Floor Tom   |                                | Clip on or boom    |
| 16      | Down Stage Center Drum Area   |                                | Tall Boom          |
|         |                               |                                |                    |
|         |                               |                                |                    |